



**EXHAUST
TRACK SPOT LIGHT**
INSTRUCTION MANUAL US
MANUEL D'UTILISATION É.-U.
MANUAL DE INSTRUCCIONES (EE. UU.)




BUSTERANDPUNCH.COM
L0134

CONTENTS

EXHAUST / TRACK SPOT LIGHT



x1



x1

x1

x2

Items boxed separately

110-120VAC / 60Hz
MAX 9W LED, GU10 BULB

110-120VAC / 60Hz
MAX 9W LED, AMPOULE GU10

110 -120 VAC /60 Hz
MÁX. 9W LED, BOMBILLA GU10



EXHAUST / INSTALLATION




1




DANGER – RISK OF SHOCK – DISCONNECT POWER BEFORE INSTALLATION

DANGER – RISQUE DE CHOC – COUPER L'ALIMENTATION AVANT L'INSTALLATION


PRECAUCION – RIESGO DE CHOQUE ELECTRICO – DESCONECTE LA CORRIENTE ANTES DE LA INSTALACIÓN



5



6




FOR USE WITH DONGGUAN TIAN SHENG
OPTIC-TRONICS CORP TRACK SYSTEM ONLY.

À utiliser uniquement avec le système de rails
Dongguan Tian Sheng Optic-Tronics Corp.

Para ser usado con Dongguan Tian Sheng
Optic-Tronics Corp sistema de riel solamente.

7



9

TURN MAINS POWER BACK ON.

METTEZ LA PUISSANCE PRINCIPALE EN
MARCHE ENCORE.

ENCENDER LA FUENTE DE ALIMENTACIÓN DE
NUEVO.

